

Sound System

To Turn on:

1. Check that sound system is turned off on back of unit



2. Monitor and main controls should be set to zero



3. Gain controls (black) should be set to zero



4. Turn unit on at power point and on back of unit

Using the system:

5. Adjust main control to approximately $\frac{1}{4}$



6. Channel 9/10 is for general audio using a 3.5mm jack (eg ipod/computer)



7. Channel 1 is for the main microphone
8. Channels 2, 5, 8 can be used for an additional microphone or musical instruments
9. Channels taped over do not work, please do not remove the tape, or attempt to use these channels



10. Once equipment is connected, adjust the volume levels using the gain switches for each channel (refer to picture 3)
11. If there is no sound, check that the mute switch has not been pressed



To turn off:

12. Turn all gains controls to zero
13. Turn off at back of unit
14. Turn off at power point